































































































3901T Compatibility Chart








Audi	2008	2007	2006	2005	2004	2003	2002	2001
A3								
A4								
A5								
A6								
A8								
Q7								
R8								
TT								

BMW	2008	2007	2006	2005	2004	2003	2002	2001
1 Series								
3 Series								
5 Series								
6 Series								
X5								

Chrysler	2008	2007	2006	2005	2004	2003	2002	2001
300/300c								
Aspen								
PT Cruiser								
Sebring Convertible								
Sebring Sedan								

Citroen	2008	2007	2006	2005	2004	2003	2002	2001
C2								
C3								
C4								
C5								
C6								
Jumper								
Jumpy								

Dodge	2008	2007	2006	2005	2004	2003	2002	2001
Avenger								
Caliber								
Charger								
Dakota								
Durango								
Magnum								
RAM								
Sprinter								

Fiat	2008	2007	2006	2005	2004	2003	2002	2001
500								
Alfa Romeo 159								
Bravo								

Croma								
Ducato								
Grande Punto								
Linea								
Panda								
Scudo								
Stilo								

Jeep	2008	2007	2006	2005	2004	2003	2002	2001
Commander								
Compass								
Grand Cherokee								
Patriot								

Lancia	2008	2007	2006	2005	2004	2003	2002	2001
Ypsilon								























































Mercedes Benz	2008	2007	2006	2005	2004	2003	2002	2001
A Class								
B Class								
C Class								
E Class								
Sprinter								
Viano								
Vito								

Peugeot	2008	2007	2006	2005	2004	2003	2002	2001
207								
307								
308								
407								
Boxer								
Expert								

Porsche	2008	2007	2006	2005	2004	2003	2002	2001
Cayenne								

Seat	2008	2007	2006	2005	2004	2003	2002	2001
Altea								
CORDOBA								
Ibiza								
Leon								
Leon Facelift								
Toledo								

Skoda	2008	2007	2006	2005	2004	2003	2002	2001
FABIA								
NEW FABIA								
Octavia 2								
Octavia Tour								
Roomster								

Superb								
Volkswagen	2008	2007	2006	2005	2004	2003	2002	2001
Caddy								
CARAVELE								
Crafter								
EOS								
Golf4								
Golf5								
Jetta								
MULTIVAN								
Passat								
Polo Mark IV								
Polo Mark IVF								
Tiguan								
Touareg								
Touran								
TRANSPORTER								

Number of keys required to program kit: 0

Number of keys required for kit operation: 0

(C) Powered by BypassKit.com